



Damp maintenance equipment

Sponge without abrasive

	Equipment used	Cleaning products	Cleaning methods
First use		Alkaline detergent	<ul style="list-style-type: none"> • Manual cleaning with an alkaline detergent + sponge without abrasive • Recovery of water with a microfibre disposable mop • Rinsing with clear water
Daily care Once a day		Neutral detergent or disinfectant detergent	<ul style="list-style-type: none"> • Manual cleaning with a sponge without abrasive + neutral detergent for the surfaces located in areas 1 or 2 and a disinfectant detergent for the surfaces located in areas 3 and 4 and eventually in area 2 • Steam cleaning
Periodical cleaning Once a month and at patient's departure in areas 1 and 2 Once a week and at patient's departure in areas 3 and 4		Alkaline detergent	<ul style="list-style-type: none"> • Manual cleaning with a disinfectant detergent (without amine) and a sponge without abrasive or • Steam cleaning (if manual daily maintenance)
Deep cleaning Once a day		Alkaline detergent	<ul style="list-style-type: none"> • Manual cleaning with an alkaline detergent + a sponge without abrasive • Rinsing with clear water

CLEANING METHOD FOR:

Mural Calypso / Mural Ultra Design / Mural Club / Mural Plus